Atlas desk

08480 The Atlas desk is a compact piece of furniture offering maximum functionality in a confined space.

The design of the bureau matches perfectly with the Atlas wardrobe gamut.

Storage cabinet

- 2 side panels with a front lath, a back and a bottom.
- The panels are connected to each other by means of eccentric cams and wooden dowels.
- The back is 13 mm thick and is milled into a groove in the side panels.
- The panels are made of melaminated or veneered (*) chipboard of 19 mm.
- The storage cabinet can be installed on the right or left side (Type A or B).
- The storage cabinet is equipped with synthetic glides.

Support

- Round solid beech post Ø 55 mm with a chromium accent.
- Strong metal attachment.
- The support is protected by a coat of varnish.
- The metal parts are protected by a light grey epoxy coating.
- The underside of the tabletop has no side rails, so that a free height of 73, 5 cm is always guaranteed.
 Thanks to this, the Atlas desk is very convenient for wheelchair users.

Tabletop

- Made of a 24 mm double-sided stratified MDF board.
- The tabletop has rounded corners and edges.
- The tabletop is finished with a HPL layer.
- The edges are protected by a coat of varnish.
- A solid laminate tabletop of 12 mm thick is available (*).

Version with drawer and storage cabinet

- The drawer is installed in the frame by means of steel rails.
- The storage cabinet has a removable shelf of 13 mm
- High-quality self-closing hinges, opening up to 135°.

Version with drawer and refrigerator

- The drawer is installed in the frame by means of steel rails.
- Noiseless absorption refrigerator "Dometic Minicool-Silencio DS 400 BI", capacity of 37 litres.
- Door with HPL finishing (same colour as the frame).
- Interior lighting with LED.
- Spiral cable.

Version with 4 drawers


- The drawer is installed in the frame by means of steel rails.

Colours


We would like to refer to our extensive colour gamut. Sample card + samples available on request.




Version with drawer and storage cabinet



Version with drawer and refrigerator



Version with 4 drawers



Materials and finishing

- Wood: beech (solid, veneered), chipboard (melaminated, stratified), MDF (stratified).
- PVC border er veneer.
- Synthetic.

For further information about used materials, constructions and maintenance: consult our materialfiles.

Options

- Veneered finishing.
- Refrigerator.
- Solid laminate tabletop of 12 mm thick.

