

# Atlas Top cabinet

The modular Atlas wardrobe and cabinet range offers you three types with the following external dimensions:

- Small: height: 77 cm - depth: 52,5 cm
- Medium: height: 99 cm - depth: 52,5 cm
- Large: height: 186 cm - depth: 56 cm

## Frame

- 2 side panels with a front lath, back and bottom.
- 2 reinforcement laths on the top side and a tabletop.
- The tabletop has rounded corners in double-sided stratified MDF board. Thickness: 24 mm.
- The panels are made of melaminated or veneered (\*) chipboard (thickness: 19 mm).
- The panels are joined together by eccentric cams and dowels.
- The back is milled into a groove in the side panels.

## Interior finishing depends on the chosen type

- Vertical panel in the middle (only 3 door model).

## Doors depend on the chosen type

- High-quality self-closing hinges, opening up to 135°.
- Metal design handle.


## Colours

We would like to refer to our extensive colour gamut.  
Sample card + samples available on request.

(\*) Option

## Dimension

- Model Tob cabinet: height 51 cm, length 85.5/99/125/146 cm, depth 56 cm



## Materials and finishing

- Wood: - chipboard (melaminated, beech veneer (\*)).  
- MDF (stratified).
- Withstands the common cleaning products.

For more information about the **materials, construction and maintenance**: please consult our material lists.

## Options

- Finishing in veneer.

