Fianna chair

00946 The classic design of the Fianna chairs is timeless. The high-quality materials guarantee a long life span.


Frame

- The frame is made of 2 laminated beech sides.
- The sides are connected to each other by means of a solid beech cross beam.
- The model with armrests can be easily hung onto the table, which makes it easier to clean the area.
- The armrests are connected to the frame, which guarantees a strong and stable chair.
- The wooden parts are finished with a coat of varnish.
- The legs are equipped with synthetic glides.



DIMENSIONS

00946 | Fianna chair with armrests 53,5 x 50 x h 82 cm



Seat and backrest

- The seat and backrest are made of 12 mm ergonomic plywood.
- The seat and backrest are inserted between the wooden frame. Thanks to this, damage to the imitation leather is avoided.
- The seat is rounded in front, so that the blood circulation is not hindered.
- Upholstered with fire-retardant foam:
- seat: thickness 20 mm, density 35 kg/m³.
- backrest: thickness 10 mm, density 30 kg/m³.
- Finished with imitation leather.

Materials and finishing

- Wood: beech (Laminated, massive), plywood.
- Metal: epoxy-coating (light gray).
- Fire-retardant foam.
- Upholstery: see collection.
- Resistant to the common cleaning products.

For further information about used **materials**, **constructions** and **maintenance**: consult our materialfiles.

Colours

We would like to refer to our extensive colour gamut. Sample card + samples available on request.

